

All Reliance Foundry products are manufactured with high-quality materials for premium aesthetics and long-term durability. With proper care and maintenance, all products will withstand years of service with minimal wear and corrosion in most North American environments.

GENERAL CARE

INSPECTION

Perform routine inspection and cleaning every 6 months on all Reliance Foundry products.

- Identify and address problems as early as possible to avoid progression of damage.
- Tighten or replace loose or missing parts immediately.
- High-saline environments or high-traffic areas with abundant particulates or pollutants will require more frequent attention.

CLEANING

For neglected or damaged products, refer to "Stainless Steel Care and Maintenance" or "Powder Coating Care and Maintenance."

- Use a soft nylon brush to remove any accumulated dirt.
- Wash with mild soap or detergent.
- Rinse in clean water.
- Wipe dry with a soft cloth.

HEAVY DAMAGE

Includes structural compromises such as visible dents, cracks, breaks, and rust that can undermine the integrity of a product.

- Remove any significant rust as soon as possible to prevent worsening of damage.
- Remove heavily damaged products from service until a repair or replacement can be made.
- For broken or missing parts, contact Reliance Foundry's Sales Department to determine the availability of replacements.

This content is provided by Reliance Foundry for informational purposes only. Any mention of a specific product is not a guarantee of quality or effectiveness. Reliance Foundry is not responsible for any improper use or handling of hazardous chemicals.