

# Care and Maintenance

All Reliance Foundry products are manufactured with high-quality materials for premium aesthetics and long-term durability. With proper care and maintenance, all products will withstand years of service with minimal wear and corrosion in most North American environments.

## GENERAL CARE

### INSPECTION

*Perform routine inspection and cleaning every 6 months on all Reliance Foundry products.*

- Identify and address problems as early as possible to avoid progression of damage.
- Tighten or replace loose or missing parts immediately.
- High-saline environments or high-traffic areas with abundant particulates or pollutants will require more frequent attention.

### CLEANING

*For neglected or damaged products, refer to "Stainless Steel Care and Maintenance" or "Powder Coating Care and Maintenance."*

- Use a soft nylon brush to remove any accumulated dirt.
- Wash with mild soap or detergent.
- Rinse in clean water.
- Wipe dry with a soft cloth.

### HEAVY DAMAGE

*Includes structural compromises such as visible dents, cracks, breaks, and rust that can undermine the integrity of a product.*

- Remove any significant rust as soon as possible to prevent worsening of damage.
- Remove heavily damaged products from service until a repair or replacement can be made.
- For broken or missing parts, contact Reliance Foundry's Sales Department to determine the availability of replacements.

This content is provided by Reliance Foundry for informational purposes only. Any mention of a specific product is not a guarantee of quality or effectiveness. Reliance Foundry is not responsible for any improper use or handling of hazardous chemicals.