

Ø12 3/4-

Ø12 1/8-

Ø13 1/8-

Ø14 1/8





Installation Sample with 5/16" Chain Accessories

IANCE FOUND



Bollard Chain Eye 3/8" (Powder Coated)



Quick Link Connector 5/16" (Powder Coated)



Bollard Chain 5/16" (Powder Coated)

Optional Accessories:

- O Chain Eye
- O Quick link
- O Chain (5/16")

See Reliance Foundry's optional accessories at: www.reliance-foundry.com/bollard/accessories-bollards

General Description:

The R-7535 Decorative Bollard features a classic column design with vertical fluting and a slightly rounded top. Made from versatile ductile iron, its wide body suits larger pipe reinforcement (up to 10-3/4" diameter) for better impact protection. Bollard surfaces are protected by a durable powder coating, available in 6 standard colors, to prevent wear and corrosion. Use as fixed, stand-alone bollards or cover impact-resistant security posts.

Specifications:

Height: 39"

Base Diameter: 14 1/8" Weight: 187 lbs (Bollard Only)

Material: Ductile Iron

Max. Interior Security Post Size: 10 3/4" x 36" (Diameter x Height)

Finish Options:

Polyester Powdercoated

See Reliance Foundry's standard color options at: www.reliance-foundry.com/bollard/colors-bollards

Installation Options:

O Fixed - Anchor Casting in New Concrete

(see sheet 2 of 9)

O Fixed - Concrete Insert Anchor in Existing Concrete (see sheet 3 of 9)

O Fixed - Adhesive Anchor in Existing Concrete

(see sheet 4 of 9) O Fixed - Anchor Casting with Concrete Form

(see sheet 5 of 9)

O Post Cover - New Post in New Concrete

(see sheet 6 of 9) O Post Cover - New Post in Existing Concrete

(see sheet 7 of 9) O Post Cover - Existing Post with Adhesive Anchor

(see sheet 8 of 9)

O Post Cover - Existing Post with Concrete Anchor (see sheet 9 of 9)

For more information on bollard post installation, please visit: www.reliance-foundry.com/bollard/installation-bollards

Care and Maintenance:

Reliance's line of bollards are finished with a long-lasting powder-coating. Proper care and maintenance are required. Regularly-performed inspections and routine cleaning will ensure that a bollard retains its aesthetic appeal and does not become damaged by the elements.

See Reliance Foundry's maintenance guide at: www.reliance-foundry.com/bollard/maintenance-bollards

RELIANCE FOUNDRY — SINCE 1925 —


Unit 207, 6450 - 148 Street, Surrey, BC V3S 7G7, Canada 1-877-789-3245 info@reliance-foundry.com www.reliance-foundry.com

Bollard R-7535


SIZE DWG NO REV R7535 C4 NOT TO SCALE SHEET 1 OF 9


THIS PLAN DRAWING AND DESIGN ARE, AND AT ALL TIMES REMAIN, THE EXCLUSIVE PROPERTY OF RELIANCE FOUNDRY CO. LTD.


TITLE





3 **4**











4 2

